

# CSFM Certifications

Part Number	Listing Number	Category
1451	7300 - 1645 : 0119	Misc. Device/Control Unit Accessories
1451-24	7300 - 1645 : 0119	Misc. Device/Control Unit Accessories
320PI	7167 - 1645 : 0150	Control Unit (Household)
3460	7167 - 1645 : 0185	Control Unit (Household)
4100SM	7300 - 1645 : 0117	Misc. Device/Control Unit Accessories
4101SN-XX	7300 - 1645 : 0147	Misc. Device/Control Unit Accessories
4110DL	7167 - 1645 : 0107	Control Unit (Household)
4110XM	7167 - 1645 : 0107	Control Unit (Household)
4140XMP	7167 - 1645 : 0106	Control Unit (Household)
4146	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
4190SN	7300 - 1645 : 0127	Misc. Device/Control Unit Accessories
4190WH	7165 - 1645 : 0111	Control Unit (Non High-Rise)
4192CP	7271 - 1645 : 0113	Ionization Smoke Detector
4192SDM	7272 - 1645 : 0137	Photoelectric Smoke Detector
4192SDTM	7272 - 1645 : 0137	Photoelectric Smoke Detector
4193SN	7300 - 1645 : 0127	Misc. Device/Control Unit Accessories
4204	7300 - 1645 : 0117	Misc. Device/Control Unit Accessories
4204CF	7300 - 1645 : 0126	Misc. Device/Control Unit Accessories
4208	7165 - 1645 : 0111	Control Unit (Non High-Rise)
4208SN	7300 - 1645 : 0131	Misc. Device/Control Unit Accessories
4208SNF	7300 - 1645 : 0131	Misc. Device/Control Unit Accessories
4208U	7300 - 1645 : 0131	Misc. Device/Control Unit Accessories
4209U	7300 - 1645 : 0130	Misc. Device/Control Unit Accessories
4297	7300 - 1645 : 0122	Misc. Device/Control Unit Accessories
472462	7165 - 1645 : 0146	Control Unit (Non High-Rise)

Part Number	Listing Number	Category
472462A	7165 - 1645 : 0146	Control Unit (Non High-Rise)
472490 (5800ADT)	7300 - 1645 : 0145	Misc. Device/Control Unit Accessories
472491	7300 - 1645 : 0144	Misc. Device/Control Unit Accessories
472491D	7300 - 1645 : 0144	Misc. Device/Control Unit Accessories
472511	7165 - 1645 : 0146	Control Unit (Non High-Rise)
472514	7165 - 1645 : 0146	Control Unit (Non High-Rise)
502	7270 - 1645 : 0101	Heat Detector
504	7270 - 1645 : 0101	Heat Detector
5110XM	7165 - 1645 : 0124	Control Unit (Non High-Rise)
5120XM	7165 - 1645 : 0125	Control Unit (Non High-Rise)
5137ADR	7165 - 1664 : 0111	Control Unit (Non High-Rise)
5140DLM	7165 - 1645 : 0111	Control Unit (Non High-Rise)
5140LED	7165 - 1645 : 0111	Control Unit (Non High-Rise)
5140MPS-1	7150 - 1645 : 0118	Boxes/Pull Stations
5140MPS-2	7150 - 1645 : 0118	Boxes/Pull Stations
5140XM	7165 - 1645 : 0111	Control Unit (Non High-Rise)
5192SD	7272 - 1645 : 0140	Photoelectric Smoke Detector
5192SDT	7272 - 1645 : 0140	Photoelectric Smoke Detector
5700	7167 - 1645 : 0104	Control Unit (Household)
5706	7272 - 1645 : 0105	Photoelectric Smoke Detector
5707	7272 - 1645 : 0105	Photoelectric Smoke Detector
5800CO	5278 - 1645 : 0190	
5800RP	7300 - 1645 : 0163	Misc. Device/Control Unit Accessories
5800WAVE	7300 - 1645 : 0162	Misc. Device/Control Unit Accessories

Part Number	Listing Number	Category
5806	7272 - 1645 : 0105	Photoelectric Smoke Detector
5807	7272 - 1645 : 0105	Photoelectric Smoke Detector
5807LS	7257 - 1645 : 0148	Single/Multiple Station Smoke Detector-Photoelectric
5807LST	7257 - 1645 : 0148	Single/Multiple Station Smoke Detector-Photoelectric
5808	7257 - 1645 : 0129	Single/Multiple Station Smoke Detector-Photoelectric
5808C	7272 - 1645 : 0138	Photoelectric Smoke Detector
5808LST	7272 - 1645 : 0143	Photoelectric Smoke Detector
5809	7270 - 1645 : 0139	Heat Detector
5809F	7270 - 1645 : 0139	Heat Detector
5815	7300 - 1645 : 0112	Misc. Device/Control Unit Accessories
5816	7300 - 1645 : 0112	Misc. Device/Control Unit Accessories
5817	7300 - 1645 : 0112	Misc. Device/Control Unit Accessories
5817CB	7300 - 1645 : 0157	Misc. Device/Control Unit Accessories
5827	7300 - 1645 : 0112	Misc. Device/Control Unit Accessories
5881EH	7300 - 1645 : 0128	Misc. Device/Control Unit Accessories
5881ENH	7300 - 1645 : 0128	Misc. Device/Control Unit Accessories
5881ENHC	7300 - 1645 : 0156	Misc. Device/Control Unit Accessories
5881ENL	7300 - 1645 : 0128	Misc. Device/Control Unit Accessories
5881ENM	7300 - 1645 : 0128	Misc. Device/Control Unit Accessories
5881H	7300 - 1645 : 0112	Misc. Device/Control Unit Accessories
5881L	7300 - 1645 : 0112	Misc. Device/Control Unit Accessories
5881M	7300 - 1645 : 0112	Misc. Device/Control Unit Accessories
5883H	7300 - 1645 : 0159	Misc. Device/Control Unit Accessories
5883M	7300 - 1645 : 0159	Misc. Device/Control Unit Accessories

Part Number	Listing Number	Category
6128B	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6128RF	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories
6128WL	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories
6137B	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6137RFB	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories
6138	7300 - 1645 : 0114	Misc. Device/Control Unit Accessories
6139	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6139B	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6139R	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6148	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6148PL2	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6148SP	7300 - 1645 : 0177	Misc. Device/Control Unit Accessories
6149EX	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6149FR	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6150	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6150AAA	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6150A-Bay	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6150ADT	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6150ADTFR	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6150APX	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6150PL2	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6150PL3	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6150RF	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories
6150RFAAA	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories
6150RFADT	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories

# CSFM Certifications

Part Number	Listing Number	Category
6150RFADTFR	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories
6150RFAPX	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories
6150RFASG	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories
6150RFCF	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories
6150RFFR	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories
6150RFMT	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories
6150RFPL2	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories
6150RFPL3	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories
6150V	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6150VADT	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6151	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6151FR	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6151US	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6160	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6160AAA	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6160CR	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6160CR-2	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6160PL2	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6160PL3	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6160RF	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories
6160RFMT	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories
6160RFPL2	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories
6160SNA	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
6160V	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6160VADT	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories

Part Number	Listing Number	Category
6160VBAY	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6164	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6164SP	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6164US	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6165EX	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6270	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6270ADT	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6270PL2	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6271C	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6271CV	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6271V	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6271VADT	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6280S	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6280W	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
6701	7167 - 1645 : 0168	Control Unit (Household)
6801	7167 - 1645 : 0168	Control Unit (Household)
685	7165 - 1645 : 0102	Control Unit (Non High-Rise)
7125	7167 - 1645 : 0170	Control Unit (Household)
7125F	7165 - 1645 : 0171	Control Unit (Non High-Rise)
745VSD3	7300 - 1645 : 0187	Misc. Device/Control Unit Accessories
745X3	7300 - 1645 : 0179	Misc. Device/Control Unit Accessories
746-32	7300 - 1645 : 0179	Misc. Device/Control Unit Accessories
7720ULF	7165 - 1645 : 0116	Control Unit (Non High-Rise)
7720ULFPLUS	7165 - 1645 : 0116	Control Unit (Non High-Rise)
7800ADT	7300 - 1645 : 0158	Misc. Device/Control Unit Accessories

Part Number	Listing Number	Category
7810iR	7300 - 1645 : 0161	Misc. Device/Control Unit Accessories
7810iR-ent	7300 - 1645 : 0161	Misc. Device/Control Unit Accessories
7835CF	7300 - 1645 : 0142	Misc. Device/Control Unit Accessories
7845C	7300 - 1645 : 0160	Misc. Device/Control Unit Accessories
7845CF	7300 - 1645 : 0160	Misc. Device/Control Unit Accessories
7845CV2	7300 - 1645 : 0160	Misc. Device/Control Unit Accessories
7845CZ	7300 - 1645 : 0160	Misc. Device/Control Unit Accessories
7845CZF	7300 - 1645 : 0160	Misc. Device/Control Unit Accessories
7845GSM	7300 - 1645 : 0183	Misc. Device/Control Unit Accessories
7845i	7300 - 1645 : 0155	Misc. Device/Control Unit Accessories
7845iENT	7300 - 1645 : 0155	Misc. Device/Control Unit Accessories
7845i-ENTF	7300 - 1645 : 0155	Misc. Device/Control Unit Accessories
7845i-GSM	7300 - 1645 : 0186	Misc. Device/Control Unit Accessories
7847i	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
7847iL	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
7900	7300 - 1645 : 0110	Misc. Device/Control Unit Accessories
7920SE	7300 - 1645 : 0109	Misc. Device/Control Unit Accessories
8132	7300 - 1645 : 0155	Misc. Device/Control Unit Accessories
8132i	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
8142	7300 - 1645 : 0155	Misc. Device/Control Unit Accessories
8142i	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
8150	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
8160	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
8950T	7300 - 1645 : 0153	Misc. Device/Control Unit Accessories
AD12612	7300 - 1645 : 0165	Misc. Device/Control Unit Accessories

Part Number	Listing Number	Category
ADT Safewatch Quick Connect	7167 - 1645 : 0141	Control Unit (Household)
ADT Safewatch Quick Connect (LYNX-2FR)	7167 - 1645 : 0141	Control Unit (Household)
APX3000	7167 - 1645 : 0141	Control Unit (Household)
APX3000SIA	7167 - 1645 : 0141	Control Unit (Household)
APX32	7167 - 1645 : 0141	Control Unit (Household)
APX32EN	7167 - 1645 : 0141	Control Unit (Household)
APX32ENSIA	7167 - 1645 : 0141	Control Unit (Household)
APX32SIA	7167 - 1645 : 0141	Control Unit (Household)
AVS-APX	7167 - 1645 : 0150	Control Unit (Household)
BHS - 3000A	7167 - 1645 : 0185	Control Unit (Household)
BHS - 3000B	7167 - 1645 : 0185	Control Unit (Household)
BHS - 3000C	7167 - 1645 : 0185	Control Unit (Household)
BHS - 3101	7167 - 1645 : 0185	Control Unit (Household)
BHS - 3111	7167 - 1645 : 0185	Control Unit (Household)
BHS - 3112	7167 - 1645 : 0185	Control Unit (Household)
BHS - 3250	7167 - 1645 : 0185	Control Unit (Household)
BHS - 3902	7167 - 1645 : 0185	Control Unit (Household)
BHS - 4000A	7167 - 1645 : 0185	Control Unit (Household)
BHS-3440	7167 - 1645 : 0185	Control Unit (Household)
CFLYNXR-EN	7167 - 1645 : 0141	Control Unit (Household)
CFV15P	7167 - 1645 : 0150	Control Unit (Household)
CFV15PCN	7167 - 1645 : 0150	Control Unit (Household)
COMP6100	7167 - 1645 : 0100	Control Unit (Household)



Part Number	Listing Number	Category
CP150KP	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
DCID	7167 - 1645 : 0141	Control Unit (Household)
DESTINY-4100	7167 - 1645 : 0100	Control Unit (Household)
DESTINY-6100	7167 - 1645 : 0101	Control Unit (Household)
DESTINY-6100AN	7167 - 1645 : 0100	Control Unit (Household)
Enterpreneur 4000EN	7167 - 1645 : 0150	Control Unit (Household)
Entrepreneur 3000EN	7167 - 1645 : 0150	Control Unit (Household)
Entrepreneur 3000i	7167 - 1645 : 0150	Control Unit (Household)
FA110C	7167 - 1645 : 0180	Control Unit (Household)
FA120C	7167 - 1645 : 0180	Control Unit (Household)
FA130CP	7167 - 1645 : 0150	Control Unit (Household)
FA130CPSIA	7167 - 1645 : 0150	Control Unit (Household)
FA142C	7167 - 1645 : 0180	Control Unit (Household)
FA145C	7167 - 1645 : 0180	Control Unit (Household)
FA148C	7167 - 1645 : 0120	Control Unit (Household)
FA148CP	7167 - 1645 : 0150	Control Unit (Household)
FA148CPCN (FA148CP-CN)	7167 - 1645 : 0150	Control Unit (Household)
FA148CPSIA	7167 - 1645 : 0150	Control Unit (Household)
FA1600C	7165 - 1645 : 0123	Control Unit (Non High-Rise)
FA1600CA	7167 - 1645 : 0176	Control Unit (Household)
FA160C	7167 - 1645 : 0181	Control Unit (Household)
FA162C	7167 - 1645 : 0181	Control Unit (Household)
FA1660C	7167 - 1645 : 0108	Control Unit (Household)

Part Number	Listing Number	Category
FA166OCSIA	7167 - 1645 : 0150	Control Unit (Household)
FA1670C	7165 - 1645 : 0123	Control Unit (Non High-Rise)
FA168C	7167 - 1645 : 0150	Control Unit (Household)
FA168C-CN	7167 - 1645 : 0150	Control Unit (Household)
FA168C-GP	7167 - 1645 : 0150	Control Unit (Household)
FA168CPS	7167 - 1645 : 0150	Control Unit (Household)
FA168CPSSIA	7167 - 1645 : 0150	Control Unit (Household)
FA1700C	7165 - 1645 : 0123	Control Unit (Non High-Rise)
FA2000C	7165 - 1645 : 0182	Control Unit (Non High-Rise)
FA215KP	7300 - 1645 : 0177	Misc. Device/Control Unit Accessories
FA215KP	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
FA220KP	7300 - 1645 : 0177	Misc. Device/Control Unit Accessories
FA220KP-SP	7300 - 1645 : 0177	Misc. Device/Control Unit Accessories
FA250KP	7300 - 1645 : 0174	Misc. Device/Control Unit Accessories
FA260KP	7300 - 1645 : 0152	Misc. Device/Control Unit Accessories
FA260RF	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories
FA270KP	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
FA270RF	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories
FA270VKP	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
FA271KP	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
FA450KP	7300 - 1645 : 0174	Misc. Device/Control Unit Accessories
FA5140MPS-1	7150 - 1645 : 0175	Boxes/Pull Stations
FA550KP	7300 - 1645 : 0174	Misc. Device/Control Unit Accessories
FA560KP	7300 - 1645 : 0177	Misc. Device/Control Unit Accessories
FA560VKP	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories

Part Number	Listing Number	Category
FA570CR	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
FA570KP	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
FA570RF	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories
FA570VKP	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
FA574KP	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
FA6150KP-GP	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
FA6150RF-GP	7300 - 1645 : 0151	Misc. Device/Control Unit Accessories
FA700KP	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
FA701CKP	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
FA701CVKP	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
FA701VKP	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
FA800KP	7300 - 1645 : 0155	Misc. Device/Control Unit Accessories
FA800KPi	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
FA850KP	7300 - 1645 : 0155	Misc. Device/Control Unit Accessories
FA850KPi	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
FOCUS 200 PLUS	7165 - 1645 : 0146	Control Unit (Non High-Rise)
FOCUS CADET	7165 - 1645 : 0146	Control Unit (Non High-Rise)
FSA-24	7120 - 1645 : 0149	
FSA-8	7120 - 1645 : 0149	
FSASM	7120 - 1645 : 0149	
GSML	7300 - 1645 : 0183	Misc. Device/Control Unit Accessories
GSMV	7300 - 1645 : 0183	Misc. Device/Control Unit Accessories
GSMV-ADT	7300 - 1645 : 0183	Misc. Device/Control Unit Accessories
GSMV-APX	7300 - 1645 : 0183	Misc. Device/Control Unit Accessories
GSMVLP	7300 - 1645 : 0183	Misc. Device/Control Unit Accessories

Part Number	Listing Number	Category
GSMVLP-ADT	7300 - 1645 : 0183	Misc. Device/Control Unit Accessories
GSMX	7300 - 1645 : 0183	Misc. Device/Control Unit Accessories
HN1224	7135 - 1645 : 0133	Audible Devices
HS1215	7135 - 1645 : 0134	Audible Devices
HS24110	7135 - 1645 : 0134	Audible Devices
HS2415	7135 - 1645 : 0134	Audible Devices
HS2475	7135 - 1645 : 0134	Audible Devices
iCenter (AUI Keypad)	7300 - 1645 : 0155	Misc. Device/Control Unit Accessories
IGSMV	7300 - 1645 : 0183	Misc. Device/Control Unit Accessories
IGSMVCN	7300 - 1645 : 0183	Misc. Device/Control Unit Accessories
iPGSM-COM	7300 - 1645 : 0183	Misc. Device/Control Unit Accessories
iPGSM-DP	7300 - 1645 : 0183	Misc. Device/Control Unit Accessories
KX-TG2970	7300 - 1645 : 0167	Misc. Device/Control Unit Accessories
LEGEND 70 Model 6700	7167 - 1645 : 0168	Control Unit (Household)
LEGEND 80 Model 6800	7167 - 1645 : 0168	Control Unit (Household)
LYNX	7167 - 1645 : 0141	Control Unit (Household)
LYNX DM-GSM	7300 - 1645 : 0183	Misc. Device/Control Unit Accessories
LYNX Plus Series	7167 - 1645 : 0141	Control Unit (Household)
Lynx Touch series	7167 - 1645 : 0141	Control Unit (Household)
LYNXDM-GSM	7300 - 1645 : 0184	Misc. Device/Control Unit Accessories
LYNX-R	7167 - 1645 : 0141	Control Unit (Household)
LYNXR-2	7167 - 1645 : 0141	Control Unit (Household)
LYNXR24	7167 - 1645 : 0141	Control Unit (Household)

Part Number	Listing Number	Category
LYNXR24-SP	7167 - 1645 : 0141	Control Unit (Household)
LYNXR-2FR	7167 - 1645 : 0141	Control Unit (Household)
LYNXR-2SIA	7167 - 1645 : 0141	Control Unit (Household)
LYNXR-EN	7167 - 1645 : 0141	Control Unit (Household)
LYNXR-ENSIA	7167 - 1645 : 0141	Control Unit (Household)
LYNXR-I	7167 - 1645 : 0141	Control Unit (Household)
LYNXR-IFR	7167 - 1645 : 0141	Control Unit (Household)
LYNXR-ISIA	7167 - 1645 : 0141	Control Unit (Household)
LYNXR-ISP	7167 - 1645 : 0141	Control Unit (Household)
LYNXR-SP	7167 - 1645 : 0141	Control Unit (Household)
LYNXSIA Plus	7167 - 1645 : 0141	Control Unit (Household)
LYNXSIA Plus Monitronics	7167 - 1645 : 0141	Control Unit (Household)
Monitronics LYNXR-I	7167 - 1645 : 0141	Control Unit (Household)
MPS-5	7150 - 1645 : 0136	Boxes/Pull Stations
MS4824 (MS4824- A)	7165 - 1645 : 0103	Control Unit (Non High-Rise)
OPTIFLEX VIDEO CONTROLLER	7300 - 1645 : 0178	Misc. Device/Control Unit Accessories
P-GATEWAY	7300 - 1645 : 0167	Misc. Device/Control Unit Accessories
PS24	7300 - 1645 : 0119	Misc. Device/Control Unit Accessories
READYGUARD	7167 - 1645 : 0141	Control Unit (Household)
ReadyGuard Plus	7167 - 1645 : 0141	Control Unit (Household)
READYGUARD- R	7167 - 1645 : 0141	Control Unit (Household)
ReadyGuardR-2	7167 - 1645 : 0141	Control Unit (Household)

Part Number	Listing Number	Category
READYGUARD-REN	7167 - 1645 : 0141	Control Unit (Household)
READYGUARD-RENSIA	7167 - 1645 : 0141	Control Unit (Household)
READYGUARD-RI	7167 - 1645 : 0141	Control Unit (Household)
REAYGUARD-RISIA	7167 - 1645 : 0141	Control Unit (Household)
RES-UL	7167 - 1645 : 0150	Control Unit (Household)
RK36	7167 - 1645 : 0100	Control Unit (Household)
RK36ADT	7167 - 1645 : 0100	Control Unit (Household)
RKLCD	7167 - 1645 : 0100	Control Unit (Household)
RKLCDADT	7167 - 1645 : 0100	Control Unit (Household)
S3101B	7167 - 1645 : 0185	Control Unit (Household)
S3111B	7167 - 1645 : 0185	Control Unit (Household)
S3112B	7167 - 1645 : 0185	Control Unit (Household)
S3201	7167 - 1645 : 0185	Control Unit (Household)
S3250	7167 - 1645 : 0185	Control Unit (Household)
SA10ADTE	7167 - 1645 : 0107	Control Unit (Household)
SAFEWATCH PRO 3000	7167 - 1645 : 0150	Control Unit (Household)
SAFEWATCH PRO 3000EN	7167 - 1645 : 0150	Control Unit (Household)
SAFEWATCH PRO 3000I	7167 - 1645 : 0150	Control Unit (Household)
SAFEWATCH PRO 4000EN	7167 - 1645 : 0150	Control Unit (Household)
Safewatch Quick Connect Plus	7167 - 1645 : 0141	Control Unit (Household)
SAVS10SE	7167 - 1645 : 0107	Control Unit (Household)

Part Number	Listing Number	Category
SAVS20P2	7167 - 1645 : 0150	Control Unit (Household)
SB1215	7125 - 1645 : 0132	Fire Alarm Devices for Hearing Impaired
SB121575	7125 - 1645 : 0132	Fire Alarm Devices for Hearing Impaired
SB24110	7125 - 1645 : 0132	Fire Alarm Devices for Hearing Impaired
SB2415	7125 - 1645 : 0132	Fire Alarm Devices for Hearing Impaired
SB241575	7125 - 1645 : 0132	Fire Alarm Devices for Hearing Impaired
SB2475	7125 - 1645 : 0132	Fire Alarm Devices for Hearing Impaired
SECURITY MANAGER 3000	7167 - 1645 : 0150	Control Unit (Household)
SECURITY MANAGER 3000EN	7167 - 1645 : 0150	Control Unit (Household)
SECURITY MANAGER 3000i	7167 - 1645 : 0150	Control Unit (Household)
Security Manager 4000EN	7167 - 1645 : 0150	Control Unit (Household)
SM12	7300 - 1645 : 0135	Misc. Device/Control Unit Accessories
SWGSM-ADT	7300 - 1645 : 0183	Misc. Device/Control Unit Accessories
SYMPHONY	7300 - 1645 : 0155	Misc. Device/Control Unit Accessories
System 1200	7167 - 1645 : 0169	Control Unit (Household)
System 3600	7167 - 1645 : 0169	Control Unit (Household)
TELESMART	7300 - 1645 : 0154	Misc. Device/Control Unit Accessories
TUXS	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
TUXW	7300 - 1645 : 0115	Misc. Device/Control Unit Accessories
UCM	7300 - 1645 : 0164	Misc. Device/Control Unit Accessories
UVS	7300 - 1645 : 0164	Misc. Device/Control Unit Accessories
UVSADT	7300 - 1645 : 0164	Misc. Device/Control Unit Accessories

Part Number	Listing Number	Category
UVSADTSL	7300 - 1645 : 0164	Misc. Device/Control Unit Accessories
UVS-QM	7300 - 1645 : 0164	Misc. Device/Control Unit Accessories
UVST	7300 - 1645 : 0164	Misc. Device/Control Unit Accessories
UVSTADTA	7300 - 1645 : 0164	Misc. Device/Control Unit Accessories
Via-30PSE	7167 - 1645 : 0107	Control Unit (Household)
Vista-100	7165 - 1645 : 0123	Control Unit (Non High-Rise)
Vista-10P	7167 - 1645 : 0150	Control Unit (Household)
Vista-10PSIA	7167 - 1645 : 0150	Control Unit (Household)
Vista-10SE	7167 - 1645 : 0107	Control Unit (Household)
Vista-128B	7167 - 1645 : 0108	Control Unit (Household)
Vista-128BP	7167 - 1645 : 0108	Control Unit (Household)
Vista-128BPADT	7167 - 1645 : 0108	Control Unit (Household)
Vista-128BPLUS	7167 - 1645 : 0108	Control Unit (Household)
Vista-128FB	7165 - 1645 : 0123	Control Unit (Non High-Rise)
Vista-128FBP	7165 - 1645 : 0123	Control Unit (Non High-Rise)
Vista-128SIA 300P1	7167 - 1645 : 0150	Control Unit (Household)
Vista-15	7167 - 1645 : 0120	Control Unit (Household)
Vista-15P	7167 - 1645 : 0150	Control Unit (Household)
Vista-15PMT	7167 - 1645 : 0150	Control Unit (Household)
Vista-15PSIA	7167 - 1645 : 0150	Control Unit (Household)
Vista-20	7167 - 1645 : 0120	Control Unit (Household)
Vista-20AMT	7167 - 1645 : 0120	Control Unit (Household)
Vista-20HW	7167 - 1645 : 0120	Control Unit (Household)
Vista20-HWSE	7167 - 1645 : 0120	Control Unit (Household)



Part Number	Listing Number	Category
Vista-20P	7167 - 1645 : 0150	Control Unit (Household)
Vista-20PBAY	7167 - 1645 : 0150	Control Unit (Household)
Vista-20PMT	7167 - 1645 : 0150	Control Unit (Household)
Vista-20PS	7167 - 1645 : 0150	Control Unit (Household)
Vista-20PSIA	7167 - 1645 : 0150	Control Unit (Household)
Vista-20SE	7167 - 1645 : 0120	Control Unit (Household)
Vista-21iP	7167 - 1645 : 0150	Control Unit (Household)
Vista-21ipSIA	7167 - 1645 : 0150	Control Unit (Household)
Vista-250BP	7167 - 1645 : 0108	Control Unit (Household)
Vista-250FBP	7165 - 1645 : 0123	Control Unit (Non High-Rise)
Vista-32FB	7165 - 1645 : 0123	Control Unit (Non High-Rise)
Vista-40	7167 - 1645 : 0108	Control Unit (Household)
Vista-48C	7167 - 1645 : 0150	Control Unit (Household)
Vista-48D	7167 - 1645 : 0150	Control Unit (Household)
Vista-50P	7167 - 1645 : 0108	Control Unit (Household)
Vista-50PEN	7167 - 1645 : 0108	Control Unit (Household)
Vista-50PENADT	7167 - 1645 : 0108	Control Unit (Household)
VISTA-GSM	7300 - 1645 : 0183	Misc. Device/Control Unit Accessories
VISTA-HM	7167 - 1645 : 0176	Control Unit (Household)
VPLEX-VSI	7300 - 1645 : 0166	Misc. Device/Control Unit Accessories
XL108	7167 - 1645 : 0169	Control Unit (Household)
XL2	7167 - 1645 : 0168	Control Unit (Household)
XL-2T	7165 - 1645 : 0173	Control Unit (Non High-Rise)
XL31	7167 - 1645 : 0169	Control Unit (Household)
XL31B	7167 - 1645 : 0169	Control Unit (Household)

# CSFM Certifications

Part Number	Listing Number	Category
XL4	7167 - 1645 : 0170	Control Unit (Household)
XL4600DL	7167 - 1645 : 0168	Control Unit (Household)
XL4605DL	7167 - 1645 : 0168	Control Unit (Household)
XL4612	7167 - 1645 : 0169	Control Unit (Household)
XL4612SM	7167 - 1645 : 0169	Control Unit (Household)
XL4613	7167 - 1645 : 0169	Control Unit (Household)
XL4760SDT	7272 - 1645 : 0172	Photoelectric Smoke Detector
XL4B	7167 - 1645 : 0170	Control Unit (Household)
XL4C	7165 - 1645 : 0171	Control Unit (Non High-Rise)
XL5	7167 - 1645 : 0170	Control Unit (Household)
XL5B	7167 - 1645 : 0170	Control Unit (Household)
XL5C	7165 - 1645 : 0171	Control Unit (Non High-Rise)
XL7125B	7167 - 1645 : 0170	Control Unit (Household)